


Installation Guide



Accessory list

Attention: The drawings below are only to be used for reference, and they may vary somewhat from the actual object. Please take this into account. Should you encounter any installation problems or missing tools, please contact customer service.



















No.


(18)


Required Parts Qty No. Part (12) Table Board (12) No. Part Qty (13) No. Qty No. Part Qty No. Qty No. Part 14) 16 3 17





-16)





















STEP8

Install desktop piercing cover and table mat.



How to Adjust Desk Height

■ "▲" Adjust the desk upwards■ "▼" Adjust the desk downwards

Instructions


Press the UP button or DOWN button to raise or lower the height of the surface.

Troubleshooting

The following tips will help you resolve common issues. If the fault or problem you encounter is not listed below, please contact the supplier.

| Fault | Method |
|---|--|
| No response when pressing down arrow while power supply connected | Check if all cables are correctly connected |
| | 2. Contact retailer or supplier |
| The desk cannot be raised | Check if overloaded, max capacity: 70kg |
| | 2. Contact retailer or supplier |
| Overload (Duty cycle: Max 2 mins on/30 mins OFF) | Should you exceed max length of operation, wait 30 minutes before using again. |
| | 2. Contact retailer or supplier |

Button





- 1. Power supply: AC100V-240V, 50/60Hz
- 2. Service environment: 0-40C
- Unplug power before cleaning, remove dust with the help of a moist cloth. Do not allow moisture to contact internal parts, do not loosen the connector.
- 4. The component box contains electric components, metals, plastics, wires etc. As such, please ensure you dispose of it in accordance with your country's environmental legislation. Do not dispose of in household waste.
- 5. Check carefully to ensure desk is correctly and fully assembled prior to use.
- 6. Familiarise yourself with all functions and settings of the product prior to using.
- 7. This product is not a toy. Do not allow children to play with the desk.
- Some noise is to be expected from the movement of the belt/braking system. This does not affect its functionality.
- Corrosive or abrasive materials must not be used to clean the equipment. Please ensure environmentally friendly products are used.
- 10. Please ensure there are no hazards in the operating environment e.g. do not leave tools unattended or for others to trip over. Always ensure you dispose of the packaging materials carefully in order to avoid any danger to children e.g. choking hazards caused by plastic.
- Keep the original packaging of the equipment if necessary, should it need to be transported on any future occasion.

Waste disposal





This marking indicates that this product should not be disposed with other household wastes. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.



info@nitro-concepts.com www.nitro-concepts.com